

FOCAL/NISSAN

INSTALLATION OF LIVE/DRIVE KITS FOR
JUKE - *May 2018*



FOCAL *INSIDE*

RECOMMENDATIONS BEFORE INSTALLATION


Reset all car radio audio settings:

- Ambience = Natural
- Bass / Midrange / Treble settings = 0
- Loudness = OFF
- Fader and Balance = Centred

The speaker drivers require a break-in period (approximately 20 hours) before they reach optimal sound quality. Start with tracks without too much low frequencies at a low volume. Then turn the sound up little by little.


After this break-in period, you can fine-tune the audio settings as you please.

ASSEMBLING THE FRONT SPEAKER DRIVERS



I - UNBOXING AND LOCATION OF PARTS


IFRA165-4



FOCAL *INSIDE*

I- UNBOXING AND LOCATION OF PARTS

IFRA165-4




FOCAL[®]INSIDE

I - UNBOXING AND LOCATION OF PARTS

IFRA165-4



sous le compartiment 2



FOCAL[®]INSIDE

II - ASSEMBLING THE FRONT SPEAKER DRIVERS

1. Equipment required for assembling the woofer



II - ASSEMBLING THE FRONT SPEAKER DRIVERS

2. Connections

a. Insert the cable into the notch



b. Before you screw, make sure that the two logos are aligned



c. Screw the 4 screws



D. Block the crossover



III - ASSEMBLING THE FRONT SPEAKER DRIVERS

1. Unclip the frontdoor panel

a. Unclip and unscrew then remove the frontdoor panel



III - ASSEMBLING THE FRONT SPEAKER DRIVERS

1. Unclip the frontdoor panel

b. Remove the door panel



III - ASSEMBLING THE FRONT SPEAKER DRIVERS

2. Remove the original speaker driver

a. Pierce the 3 rivets' head.



Some version may use screws. If so, do not use the rivet



b. Remove the rivet's body from the inside



Note :Use gloves during step b

III - ASSEMBLING THE FRONT SPEAKER DRIVERS


3. Installing the front speaker drivers

a. Rivet on the door frame and connect the Focal speaker driver.




IV - ASSEMBLING THE TWEETER

1. Equipment required for assembling the tweeter



2. Remove the tweeter's grille by simply unclipping it



IV - ASSEMBLING THE TWEETER

4. Connect at position 2



Note : Position 1 is not used in this set up

V - INSTALLING THE TWEETER

1 Put aside the door seal, then remove the door panel




Note : The green clip must be rotated by one quarter turn in order to be removed

BODY SIDE TRIM

< REMOVAL AND INSTALLATION >

Do not re-use clips, if part is removed.

○ : Clip



FOCAL *INSIDE*

V - INSTALLING THE TWEETER

- 2 Remove the tweeter then unscrew its holder




V - INSTALLING THE TWEETER

3 Adapt the holder to the Focal tweeter


a. Cut the connector on the side



b. Screw back the tweeter putting a washer between the screw and the holder




The washer is not provided.
A 2mm-thin washer is
needed



Note: To fix the Focal tweeter on its holder, you have to use a washer.
Without a 2mm-thin washer, THE TWEETER WILL BREAK!

V - INSTALLING THE TWEETER

4 Connectors needed for tweeters wiring






V - INSTALLING THE TWEETER

5 Remove the stereo



V - INSTALLING THE TWEETER

6 Connect to the stereo



V - INSTALLING THE TWEETER

7 Wiring of the tweeters from the stereo

a. Left tweeter

3



2



1





Note : Black and white connectors

V - INSTALLING THE TWEETER

7 Wiring of the tweeters from the stereo

b. Connexion et fixation du Tweeter Gauche



 **Note** : Clip the small tab of the holder on the upper part, and the big tab on the lower part

V - INSTALLING THE TWEETER

7 Wiring of the tweeters from the stereo

c. Right tweeter - remove the glove box



V - INSTALLING THE TWEETER

7

c. Right tweeter - Black and grey - remove the glove box then put the wiring underneath it




V - INSTALLING THE TWEETER


7 Wiring of the tweeters from the stereo

d. Connect and fix the right tweeter



 **Note :** Clip the small tab of the holder on the upper part, and the big tab on the lower part

ASSEMBLING THE REAR SPEAKER DRIVERS



VI - ASSEMBLING THE REAR SPEAKER DRIVERS

1. Unclip the reardoor panel


a. Unclip and unscrew the door panel



VI - ASSEMBLING THE REAR SPEAKER DRIVERS

1. Unclip the reardoor panel

b. Remove the door panel




III - ASSEMBLING THE REAR SPEAKER DRIVERS

2. Remove the original speaker driver

a. Pierce the 3 rivets' head.



Some version may use screws. If so, do not use the rivet



b. Remove the rivet's body from the inside




Note :Use gloves during step b

VI - ASSEMBLING THE REAR SPEAKER DRIVERS

3. Installing the Rear speaker drivers

a. Rivet on the door frame and connect the Focal speaker driver.



Note : Rotate the tweeter upward

The Focal speakers improve the acoustical performances of your vehicle using exclusive technologies.
Enjoy your favorite songs while driving !



Break-in period
The system will reach its optimal level after 20 hours of listening.

ALL THE ORIGINAL SETTINGS OF YOUR RADIO CAR STILL WORK AS SPECIFIED IN THE VEHICLE'S USER MANUAL.

FOCAL[®] *INSIDE*

www.focal-inside.com