

FOCAL/NISSAN

INSTALLATION OF LIVE / DRIVE FOR
QASHQAI - *May 2018*



FOCAL *INSIDE*

RECOMMENDATIONS BEFORE INSTALLATION


Reset all car radio audio settings:

- Ambience = Natural
- Bass / Midrange / Treble settings = 0
- Loudness = OFF
- Fader and Balance = Centred

The speaker drivers require a break-in period (approximately 20 hours) before they reach optimal sound quality. Start with tracks without too much low frequencies at a low volume. Then turn the sound up little by little.


After this break-in period, you can fine-tune the audio settings as you please.

ASSEMBLING THE FRONT SPEAKER DRIVERS



I - UNBOXING AND LOCATION OF PARTS

IFR 165-4



FOCAL *INSIDE*

I- UNBOXING AND LOCATION OF PARTS

IFR 165-4



Compartment 2
(Under the 1st)




FOCAL[®]INSIDE

I - UNBOXING AND LOCATION OF PARTS

IFR 165-4



Under compartment 2



FOCAL[®]INSIDE

II - ASSEMBLING THE FRONT SPEAKER DRIVERS

1. Equipment required for assembling the woofer



II - ASSEMBLING THE FRONT SPEAKER DRIVERS

2. Connections

a. Insert the cable into the notch



b. Before you screw, make sure that the two logos are aligned



c. Screw the 4 screws



D. Block the crossover




III - ASSEMBLING THE FRONT SPEAKER DRIVERS

1. Unclip the frontdoor panel

a. Unclip and unscrew then remove the frontdoor panel




+



III - ASSEMBLING THE FRONT SPEAKER DRIVERS

1. Unclip the frontdoor panel

b. Remove the door panel



III - ASSEMBLING THE FRONT SPEAKER DRIVERS

2. Remove the original speaker driver

a. Pierce the 3 rivets' head.



Some version may use screws. If so, do not use the rivet



b. Remove the rivet's body from the inside



Note :Use gloves during step b

III - ASSEMBLING THE FRONT SPEAKER DRIVERS


3. Installing the front speaker drivers

a. Rivet on the door frame and connect the Focal speaker driver.




IV - ASSEMBLING THE TWEETER

1. Equipment required for assembling the tweeter




2. Remove the tweeter's grille by simply unclipping it



IV - ASSEMBLING THE TWEETER

3. Slot the tweeter into the spacer making sure it's the right way up



 **Note:** Dispose the parts in this very position.

4. Connect at position 2



 **Note:** Position 1 is not used in this set up

V - INSTALLING THE TWEETER

- 1 Put aside the door seal, then remove the door panel




Note : The green clip must be rotated by one quarter turn in order to be removed

BODY SIDE TRIM

< REMOVAL AND INSTALLATION >

Do not re-use clips, if part is removed.



○ : Clip



FOCAL *INSIDE*



V - INSTALLING THE TWEETER

2 Remove the top of the dashboard to access the tweeters




Note : Pay attention to the central sensor removing the dashboard

3 Connect the Focal tweeter and place the Focal logo



ASSEMBLING THE REAR SPEAKER DRIVERS



VI - ASSEMBLING THE REAR SPEAKER DRIVERS

1. Unclip the reardoor panel

a. Unclip and unscrew the door panel



VI - ASSEMBLING THE REAR SPEAKER DRIVERS

1. Unclip the reardoor panel

b. Remove the door panel




III - ASSEMBLING THE REAR SPEAKER DRIVERS

2. Remove the original speaker driver

a. Pierce the 3 rivets' head.



Some version may use screws. If so, do not use the rivet



b. Remove the rivet's body from the inside




Note :Use gloves during step b

VI - ASSEMBLING THE REAR SPEAKER DRIVERS

3. Installing the Rear speaker drivers

a. Rivet on the door frame and connect the Focal speaker driver.



Note : Rotate the tweeter upward

The Focal speakers improve the acoustical performances of your vehicle using exclusive technologies.
Enjoy your favorite songs while driving !



Break-in period
The system will reach its optimal level after 20 hours of listening.

ALL THE ORIGINAL SETTINGS OF YOUR RADIO CAR STILL WORK AS SPECIFIED IN THE VEHICLE'S USER MANUAL.

FOCAL[®] *INSIDE*

www.focal-inside.com